BETWEEN SERIES ADAPTERS



# Between Series Adapters

# Between Series Adapters

## AMC Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| 031-6101 | AMC Jack to TNC Jack R/P | Brass, 2- Hole Flange |
| 031-6109 | AMC Jack to BNC Jack R/P (special) | Brass |
| 031-6112 | AMC Jack to TNC Jack R/P (standard) | Brass, Bulkhead |
| 901-10097 | AMC Jack to SMA Jack R/P | Brass |

## MMCX Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| 908-31100 | MMCX Plug to SMA Jack | Brass/Beryllium Copper |
| APH-SMAJ-MMCXP | MMCX Plug to SMA Jack | Brass |
| 908-32101 | MMCX Jack to SMA Plug | Brass/Beryllium Copper |
| APH-SMAP-MMCXJ | MMCX Jack to SMA Plug | Brass |
| APH-SMAP-MMCXP | MMCX Plug to SMA Plug | Brass |
| APH-SMAJ-MMCXJ | MMCX Jack to SMA Jack | Brass |

## MCX Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| APH-SMAP-MCXJ | MCX Jack to SMA Plug | Brass |
| APH-SMAJ-MCXP | MCX Plug to SMA Jack | Brass |
| APH-SMAP-MCXP | MCX Plug to SMA Plug | Brass |
| APH-SMAJ-MCXJ | MCX Jack to SMA Jack | Brass |

## 1.0/2.3 Between Series Adapters

| Part Number | Description | |
|---|---|---|
| 901-10005 | 1.0/2.3 Jack to SMA Plug | Stainless Stainless Steel |
| 901-10006 | 1.0/2.3 Plug to SMA Jack | Beryllium Copper |
| 901-10007 | 1.0/2.3 Plug to SMA Plug | Beryllium Copper |
| 901-10008 | 1.0/2.3 Jack to SMA Jack | Stainless Stainless Steel |

## SMB Between Series Adapters

| Part Number | Description | |
|---|---|---|
| 901-9033 | SMB Jack to SMA Jack | Stainless Stainless Steel |
| APH-SMAJ-SMBJ | SMB Jack to SMA Jack | Brass |
| APH-SMAP-SMBJ | SMB Jack to SMA Plug | Brass |
| 901-9034 | SMB Plug to SMA Jack | Brass/Stainless Stainless Steel |
| APH-SMAJ-SMBP | SMB Plug to SMA Jack | Brass |
| 901-9038 | SMB Plug to SMA Plug | Brass/Stainless Stainless Steel |
| APH-SMAP-SMBP | SMB Plug to SMA Plug | Brass |

## SMA Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| 131-91038 | SMA Plug to APC-7 | Beryllium Copper |
| APH-SMAP-MMCXJ | SMA Plug to MMCX Jack | Brass |
| 908-32101 | SMA Plug to MMCX Jack | Beryllium Copper or Brass |
| APH-SMAJ-MMCXP | SMA Jack to MMCX Plug | Brass |
| 908-31100 | SMA Jack to MMCX Plug | Beryllium Copper or Brass |
| APH-SMAP-MMCXP | SMA Plug to MMCX Plug | Brass |
| APH-SMAJ-MMCXJ | SMA Jack to MMCX Jack | Brass |
| APH-SMAP-MCXP | SMA Plug to MCX Plug | Brass |
| APH-SMAJ-MCXJ | SMA Jack to MCX Jack | Brass |
| APH-SMAP-MCXJ | SMA Plug to MCX Jack | Brass |
| APH-SMAJ-MCXP | SMA Jack to MCX Plug | Brass |
| 901-10005 | SMA Plug to 1.0/2.3 Jack | Stainless Steel |
| 901-10006 | SMA Jack to 1.0/2.3 Plug | Beryllium Copper |
| 901-10007 | SMA Plug to 1.0/2.3 Plug | Beryllium Copper |
| 901-10008 | SMA Jack to 1.0/2.3 Jack | Stainless Steel |
| 901-10097 | SMA Jack R/P to AMC Jack | Brass |
| APH-SMAP-SMBJ | SMA Plug to SMB Jack | Brass |
| APH-SMAJ-SMBP | SMA Jack to SMB Plug | Brass |
| 901-9034 | SMA Jack to SMB Plug | Stainless Steel/Brass |
| APH-SMAP-SMBP | SMA Plug to SMB Plug | Brass |
| 901-9038 | SMA Plug to SMB Plug | Stainless Steel/Brass |
| APH-SMAJ-SMBJ | SMA Jack to SMB Jack | Brass |
| 901-9033 | SMA Jack to SMB Jack | Stainless Steel |
| 930-100A-51S | SMA Jack to QMA Jack | Brass |
| 930-101A-51S | SMA Jack to QMA Plug | Brass |
| APH-SMAP-MUHFJ | SMA Plug to Mini UHF Jack | Brass |
| APH-SMAJ-MUHFP | SMA Jack to Mini UHF Plug | Brass |
| APH-SMAP-MUHFP | SMA Plug to Mini UHF Plug | Brass |
| APH-SMAJ-MUHFJ | SMA Jack to Mini UHF Jack | Brass |
| APH-SMAP-BNCJ | SMA Plug to BNC Jack | Brass |
| APH-SMAJ-BNCP | SMA Jack to BNC Plug | Brass |
| APH-SMAJ-BNCJ | SMA Jack to BNC Jack | Brass |
| APH-SMAP-BNCP | SMA Plug to BNC Plug | Brass |
| APH-SMAP-TNCJ | SMA Plug to TNC Jack | Brass |
| 901-168 | SMA Plug to TNC Plug | Beryllium Copper/Brass |
| APH-SMAP-TNCP | SMA Plug to TNC Plug | Brass |
| 901-171 | SMA Jack to TNC Jack | Beryllium Copper/Brass |
| APH-SMAJ-TNCJ | SMA Jack to TNC Jack | Brass |
| APH-SMAJ-TNCP | SMA Jack to TNC Plug | Brass |
| APH-SMAP-UHFJ | SMA Plug to UHF Jack | Brass |
| APH-SMAJ-UHFP | SMA Jack to UHF Plug | Brass |
| APH-SMAP-UHFP | SMA Plug to UHF Plug | Brass |
| APH-SMAJ-UHFJ | SMA Jack to UHF Jack | Brass |
| APH-SMAJ-NP | SMA Jack to N Plug | Brass |
| APH-SMAP-NP | SMA Plug to N Plug | Brass |
| APH-SMAJ-NJ | SMA Jack to N Jack | Brass |
| APH-SMAJ-NJBHD | SMA Jack to N Jack | Brass |
| APH-SMAP-NJ | SMA Plug to N Jack | Brass |

# Between Series Adapters

## QMA Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| 930-100A-51S | QMA Jack to SMA Jack | Brass |
| 930-101A-51S | QMA Plug to SMA Jack | Brass |

## Mini-UHF Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| 083-910-RFX | Mini-UHF Plug to UHF Plug | Brass |
| APH-SMAP-MUHFJ | Mini UHF Jack to SMA Plug | Brass |
| APH-SMAJ-MUHFP | Mini UHF Plug to SMA Jack | Brass |
| APH-SMAP-MUHFP | Mini UHF Plug to SMA Plug | Brass |
| APH-SMAJ-MUHFJ | Mini UHF Jack to SMA Jack | Brass |
| APH-MUHFP-UHFJ | Mini UHF Plug to UHF Jack | Brass |

## Type F Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| 531-40010 | Type F Jack to Type G Plug | Brass |
| APH-BNCP-FJ | Type F Jack to BNC Plug | Brass |
| APH-NJ-FJ | Type F Jack to Type N Jack | Brass |
| APH-NJ-FP | Type F Plug to Type N Jack | Brass |

## Type G Between Series Adapters

| Part Number | Description | |
|---|---|---|
| 531-40010 | Type G Plug to Type F Jack | Brass |

## BNC Between Series Adapters

| Part Number | Description | |
|---|---|---|
| 031-6109 | BNC Jack R/P to AMC Jack (special) | Brass |
| APH-BNCP-FJ | BNC Plug To Type F Jack | Brass |
| APH-SMAP-BNCJ | BNC Jack to SMA Plug | Brass |
| APH-SMAJ-BNCP | BNC Plug to SMA Jack | Brass |
| APH-SMAJ-BNCJ | BNC Jack to SMA Jack | Brass |
| APH-SMAP-BNCP | BNC Plug to SMA Plug | Brass |
| APH-BNCP-TNCJ | BNC Plug to TNC Jack | Brass |
| APH-BNCJ-TNCP | BNC Jack to TNC Plug | Brass |
| APH-BNCJ-TNCJ | BNC Jack to TNC Jack | Brass |
| APH-BNCP-TNCP | BNC Plug to TNC Plug | Brass |
| APH-BNCP-UHFJ | BNC Plug to UHF Jack | Brass |
| 031-28 | BNC Jack to UHF Plug | Brass |
| APH-BNCP-UHFP | BNC Plug to UHF Plug | Brass |
| 000-2900 | BNC Plug to UHF Jack | Brass |

## TNC Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| 031-6101 | TNC Jack R/P to AMC Jack | Brass, 2-Hole Flange |
| 031-6112 | TNC Jack R/P to AMC Jack (standard) | Brass, Bulkhead |
| 901-168 | TNC Plug to SMA Plug | Brass/Beryllium Copper |
| 901-171 | TNC Jack to SMA Jack | Brass/Beryllium Copper |
| APH-SMAP-TNCJ | TNC Jack to SMA Plug | Brass |
| APH-SMAJ-TNCP | TNC Plug to SMA Jack | Brass |
| APH-SMAP-TNCP | TNC Plug to SMA Plug | Brass |
| APH-SMAJ-TNCJ | TNC Jack to SMA Jack | Brass |
| APH-BNCP-TNCJ | TNC Jack to BNC Plug | Brass |
| APH-BNCJ-TNCP | TNC Plug to BNC Jack | Brass |
| APH-BNCJ-TNCJ | TNC Jack to BNC Jack | Brass |
| APH-BNCP-TNCP | TNC Plug to BNC Plug | Brass |
| APH-NP-TNCJ | TNC Jack to Type N Plug | Brass |
| APH-NJ-TNCP | TNC Plug to Type N Jack | Brass |
| APH-NJ-TNCJ | TNC Jack to Type N Jack | Brass |
| APH-NP-TNCP | TNC Plug to Type N Plug | Brass |

## UHF Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| 083-10 | UHF Jack to RCA Plug | Brass |
| APH-SMAP-UHFJ | UHF Jack to SMA Plug | Brass |
| APH-SMAJ-UHFP | UHF Plug to SMA Jack | Brass |
| APH-SMAP-UHFP | UHF Plug to SMA Plug | Brass |
| APH-SMAJ-UHFJ | UHF Jack to SMA Jack | Brass |
| APH-MUHFP-UHFJ | UHF Jack to Mini UHF Plug | Brass |
| APH-BNCP-UHFJ | UHF Jack to BNC Plug | Brass |
| APH-BNCP-UHFP | UHF Plug to BNC Plug | Brass |
| 000-2900 | UHF Jack to BNC Plug | Brass |
| 031-28 | UHF Plug to BNC Jack | Brass |
| APH-NP-UHFJ | UHF Jack to Type N Plug | Brass |
| 000-4400 | UHF Jack to N Plug | Brass |
| 000-14000 | UHF Plug to N Jack | Brass |
| 083-910-RFX | UHF Plug to Mini-UHF Plug | Brass |

# Between Series Adapters

## Type N Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| APH-SMAJ-NP | Type N Plug to SMA Jack | Brass |
| APH-SMAJ-NJ | Type N Jack to SMA Jack | Brass |
| APH-SMAP-NJ | Type N Jack to SMA Plug | Brass |
| APH-SMAP-NP | Type N Plug to SMA Plug | Brass |
| APH-SMAJ-NJBHD | Type N Bulkhead Jack to SMA Jack | Brass |
| APH-NJ-FJ | Type N Jack to Type F Jack | Brass |
| APH-NJ-FP | Type N Jack to Type F Plug | Brass |
| APH-NP-BNCJ | Type N Plug to BNC Jack | Brass |
| APH-NJ-BNCP | Type N Jack to BNC Plug | Brass |
| APH-NJ-BNCJ | Type N Jack to BNC Jack | Brass |
| APH-NP-BNCP | Type N Plug to BNC Plug | Brass |
| APH-NP-TNCJ | Type N Plug to TNC Jack | Brass |
| APH-NJ-TNCP | Type N Jack to TNC Plug | Brass |
| APH-NJ-TNCJ | Type N Jack to TNC Jack | Brass |
| APH-NP-TNCP | Type N Plug to TNC Plug | Brass |
| 000-4400 | Type N Plug to UHF Jack | Brass |
| 000-14000 | Type N Jack to UHF Plug | Brass |
| APH-NP-UHFJ | Type N Plug to UHF Jack | Brass |
| 000-16050 | Type N Jack to HN Plug | Brass |
| 000-16075 | Type N Plug to HN Jack | Brass |
| AFZ1-1 | Type N Jack to 7/16 Jack | Brass |
| AFZ2-1 | Type N Jack to 7/16 Plug | Brass |
| AFZ7-1 | Type N Plug to 7/16 Plug | Brass |

## HN Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| 000-16050 | HN Plug to Type N Jack | Brass |
| 000-16075 | HN Jack to Type N Plug | Brass |

## 7/16 Between Series Adapters

| Part Number | Description | Body Material |
|---|---|---|
| **AFZ3-1** | Jack-Jack | Brass |
| **AFZ4-1** | Plug-Plug | Brass |
| **AFZ5-1** | Plug-Jack | Brass |

# Notes

# Cable Group Listing

| Cable Group | Cable Type |
|---|---|
| A | RG-178, 196 |
| B | RG-174, 188A, 316, Belden 7805 |
| B1 | RG-179, 187, Belden 9221 |
| B2 | RD-188/U, RD-316/U |
| B3 | RD-179/U, AT&T 19224L2 |
| C | RG-58, 58A, 58C, 141, 303, LMR195, Belden 7806A, 9907 |
| C1 | RG-55, 142, 223, 400 |
| C2 | LMR200, Belden 7807A |
| D | RG-58/U Plenum, Thinnet, RG-122/U, Belden 88240, 89907 |
| E | RG-59, 62, 140, 210, Belden 8241, 8263, 8279, 9209 |
| E1 | RG-59/U 20 AWG center conductor, Belden 1426A, 1505A, 9100, 9278 |
| E2 | RD-59/U, Belden 8281, 9141, 9231 |
| E3 | RG-59/U Quad Shield, Belden 1152A |
| F | RG-59/U Plenum, Belden 1560A, 9259, 82259, 89259, 88241 |
| F1 | RG-59/U Plenum 20 AWG center conductor, Belden 82108 |
| G1 | RG-6, 143, 212 |
| G2 | 8X, LMR240, Belden 7808A, 9258 |
| G3 | LMR400, Belden 7810A, 8214, 9913 |
| G4 | RG-8, 8A, 9, 87A, 213, 214, 225, 393 |
| G5 | RD-6/U |
| H | RG-11 |
| H1 | Belden 1694A, 9248 |
| H2 | Belden 1859A, 7731, 8213, 9292 |
| H3 | RG-54A/U |
| I | AT&T 734A, Belden 1505A |
| I2 | AT&T 735A, Belden 735A1 |
| J | Quad 59 headend cable |
| K | LMR600 |
| K2 | Belden 1695A |
| K3 | RG-122, 180, 195, Belden 1855, 1865A, 8218 |
| L | .141 semi-rigid, RG-402/U |
| L2 | .085, .086, .087 semi-rigid, RG-405/U |
| L3 | .250 semi-rigid |
| L4 | .047 semi-rigid, Belden 1674 |
| M | 1/2 inch annular corrugated |
| M1 | 1 1/4 inch annular corrugated |
| M2 | 1 5/8 inch annular corrugated |
| M3 | 7/8 inch annular corrugated |
| N | 1/4 Helical |
| N1 | 3/8 Helical |
| N2 | 1/2 Helical |
| N3 | 7/8 inch SFC |
| P1 | .81 mm OD micro-cable |
| P2 | 1.13 mm OD micro-cable, TCB-068 |
| P3 | 1.32 mm OD micro-cable |
| P4 | 1.37 mm OD micro-cable |

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Amphenol:

APH-BNCP-UHFP APH-MUHFP-UHFJ APH-SMAJ-MUHFJ APH-SMAJ-MUHFP APH-SMAJ-NJ APH-SMAJ-UHFJ APH-SMAJ-UHFP APH-SMAP-MUHFP APH-SMAP-UHFP

# OCEAN CHIPS
## Океан Электроники
## Поставка электронных компонентов

Компания «Океан Электроники» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Поставка оригинальных импортных электронных компонентов напрямую с производств Америки, Европы и Азии, а так же с крупнейших складов мира;
- Широкая линейка поставок активных и пассивных импортных электронных компонентов (более 30 млн. наименований);
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Помощь Конструкторского Отдела и консультации квалифицированных инженеров;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Поставка электронных компонентов под контролем ВП;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- При необходимости вся продукция военного и аэрокосмического назначения проходит испытания и сертификацию в лаборатории (по согласованию с заказчиком);
- Поставка специализированных компонентов военного и аэрокосмического уровня качества (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Actel, Aeroflex, Peregrine, VPT, Syfer, Eurofarad, Texas Instruments, MS Kennedy, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Компания «Океан Электроники» является официальным дистрибьютором и эксклюзивным представителем в России одного из крупнейших производителей разъемов военного и аэрокосмического назначения «**JONHON**», а так же официальным дистрибьютором и эксклюзивным представителем в России производителя высокотехнологичных и надежных решений для передачи СВЧ сигналов «**FORSTAR**».

AVIC JONHON

**«JONHON»** (основан в 1970 г.)

Разъемы специального, военного и аэрокосмического назначения:

(Применяются в военной, авиационной, аэрокосмической, морской, железнодорожной, горно- и нефтедобывающей отраслях промышленности)

**«FORSTAR»** (основан в 1998 г.)

ВЧ соединители, коаксиальные кабели, кабельные сборки и микроволновые компоненты:

(Применяются в телекоммуникациях гражданского и специального назначения, в средствах связи, РЛС, а так же военной, авиационной и аэрокосмической отраслях промышленности).

FORSTAR®

Телефон: 8 (812) 309-75-97 (многоканальный)
Факс: 8 (812) 320-03-32
Электронная почта: ocean@oceanchips.ru
Web: http://oceanchips.ru/
Адрес: 198099, г. Санкт-Петербург, ул. Калинина, д. 2, корп. 4, лит. А