



DLP-IO8-G

LEAD-FREE

USB-BASED 8-CHANNEL DATA ACQUISITION MODULE

Features:

- 8 Channels: Digital I/O, Analog In, Temperature
- USB Port Powered
- USB 1.1 and 2.0 Compatible Interface
- Small Footprint; Easily Fits on Desktop
- Easy to Use with Single-Byte Commands - Can Utilize a Simple Terminal Emulator to Control All Functions

Applications:

- Data Acquisition
- Industrial/Process Control
- Process Monitoring

1.0 INTRODUCTION

The DLP-IO8 Data Acquisition Module is a low-cost, easy-to-use data acquisition system for measuring voltages, controlling and monitoring processes, and acquiring temperature data. Each of the 8 available channels can be configured for any of the digital, analog, or temperature modes via single-byte commands. All operational power is taken from the host PC via the USB port.

The mode of each I/O is automatically changed with each command sent. For example, if an I/O is set to Digital Output – High and then the Digital Input Mode is selected, the I/O is first changed to Input Mode and then the high/low state is read and returned to the host.

2.0 SPECIFICATIONS

The DLP-IO8 is a 5-volt system that derives its power from the host USB port. Each channel has the following capabilities:

Digital Output: Set high, or clear to low. (The actual high/low voltage depends upon sink/source current.)

Digital Input: Read the high/low state.

Analog In: Read and return the voltage on each I/O pin using a 10-bit A/D: 0-5 volt range.

Temperature: Measure temperature using a DS18B20+ digital temperature sensor (purchased separately) in the range of 67 to 257°F (-55 to 125°C).

3.0 ABSOLUTE MAXIMUM RATINGS

Stresses above those listed here may cause permanent damage to the DLP-IO8:

Operating Temperature: 0-70°C

Voltage on I/Os with Respect to Ground: -0.3V to +5.3V

Sink/Source Current on Any I/O: 25mA

4.0 WARNINGS

- Unplug from the host PC before connecting to the DLP-IO8.
- Isolate the bottom of the board from all conductive surfaces.
- Observe static precautions to prevent damage to the DLP-IO8 module.

5.0 USB DRIVERS

USB drivers for the following operating systems are available for download from the DLP Design and FTDI websites:

| | |
|------------------------|---------------|
| Windows 8 | Windows 7 |
| Windows Server 2008 R2 | Windows Vista |
| Windows XP | Mac OSX |
| Windows Server 2003 | Mac OS9 |
| Windows 2000 | Mac OS8 |
| Windows 98, ME | Linux |

NOTE: If using the dual mode drivers from FTDI (CDM2.00.00) and you want to use the Virtual COM Port (VCP) drivers then it may be necessary to disable the D2XX drivers first via Device Manager. Right click on the entry under USB Controllers that appears when the DLP-232PC is connected, select Properties, select the Advanced tab, put a check in the option for "Load VCP" and click OK. Unplug and replug the DLP-232PC and a COM port should appear in Device Manager under Ports (COM & LPT).

6.0 USING THE DLP-IO8

Simply connect the DLP-IO8 to the PC to initiate the loading of drivers. Once the drivers are loaded, the DLP-IO8 is ready for use. All commands are single-byte commands.

You can either utilize a simple terminal emulator program, or write your own program in your language of choice. Begin by opening the COM port, set the baud rate to 115200, and send single-byte commands as shown in Table 1. The Ping command can be used to locate the correct COM port used for communicating with the DLP-IO8, or you can look in Device Manager to see which port was assigned by Windows.

| TABLE 1 | | | |
|--------------------|-----------|----------------|-------------------|
| Channel 1 Commands | | | |
| ASCII Character | Hex Value | Description | Return / Comments |
| 1 | 0x31 | Dig Out – High | Nothing returned |
| Q | 0x51 | Dig Out – Low | Nothing returned |

| | | | |
|----------|------|---------------|---|
| A | 0x41 | Digital Input | Returns 0 or 1 (See Note 1) |
| Z | 0x5A | Analog In | Returns measured voltage (See Note 1) |
| 9 | 0x39 | Temperature | Returns current temperature (See Notes 1 and 2) |

| Channel 2 Commands | | | |
|---------------------------|------|----------------|--|
| 2 | 0x32 | Dig Out – High | |
| W | 0x57 | Dig Out – Low | |
| S | 0x53 | Digital Input | |
| X | 0x58 | Analog In | |
| 0 | 0x30 | Temperature | |

| Channel 3 Commands | | | |
|---------------------------|------|----------------|--|
| 3 | 0x33 | Dig Out – High | |
| E | 0x45 | Dig Out – Low | |
| D | 0x44 | Digital Input | |
| C | 0x43 | Analog In | |
| - | 0x2D | Temperature | |

| Channel 4 Commands | | | |
|---------------------------|------|----------------|--|
| 4 | 0x34 | Dig Out – High | |
| R | 0x52 | Dig Out – Low | |
| F | 0x46 | Digital Input | |
| V | 0x56 | Analog In | |
| = | 0x3D | Temperature | |

| Channel 5 Commands | | | |
|---------------------------|------|----------------|--|
| 5 | 0x35 | Dig Out – High | |
| T | 0x54 | Dig Out – Low | |
| G | 0x47 | Digital Input | |
| B | 0x42 | Analog In | |
| O | 0x4F | Temperature | |

| Channel 6 Commands | | | |
|---------------------------|------|----------------|--|
| 6 | 0x36 | Dig Out – High | |
| Y | 0x59 | Dig Out – Low | |
| H | 0x48 | Digital Input | |
| N | 0x4E | Analog In | |
| P | 0x50 | Temperature | |

| Channel 7 Commands | | | |
|---------------------------|------|----------------|--|
| 7 | 0x37 | Dig Out – High | |
| U | 0x55 | Dig Out – Low | |
| J | 0x4A | Digital Input | |
| M | 0x4D | Analog In | |
| [| 0x5B | Temperature | |

| Channel 8 Commands | | | |
|----------------------------|------|----------------|--|
| 8 | 0x38 | Dig Out – High | |
| I | 0x49 | Dig Out – Low | |
| K | 0x4B | Digital Input | |
| , (Comma) | 0x2C | Analog In | |
|] | 0x5D | Temperature | |

| Setup Commands (Remembered Until Power is Cycled) | | | |
|--|------|---------------|---|
| ` | 0x60 | Return ASCII | Default setting; nothing returned (Accent Grave character just left of the 1 key) |
| \ | 0x5C | Return Binary | Nothing returned |
| L | 0x4C | Set °F | Default setting; nothing returned |
| ; | 0x3B | Set °C | Nothing returned |

| Ping Command | | | |
|---------------------|------|------------|---|
| ' | 0x27 | Issue Ping | Q (0x51) will be returned if the DLP-IO8 is found on the selected port (Apostrophe character just right of the ; key) |

Note 1 – Data is returned in either the form of ASCII characters (ex: 1.25V, 78.2°F) or binary (raw data) depending upon the current mode. The power-up default mode is ASCII mode such that data is easily read using a terminal emulator program.

Note 2 – Requires DS18B20 digital temperature sensor (purchased separately). See Section 7.0 of this document for connection details.

7.0 TEMPERATURE

Up to eight DS18B20+ digital temperature sensors can be connected to the DLP-IO8. For best performance, use Cat 5 type computer cable to connect the sensors to the DLP-IO8. Two pairs of wires in the Cat 5 cable are required for the connection. The first pair is for Power (5V) and Ground, and the second pair is designated as Data and Ground. In addition, a pull-up resistor is required for the data line of approximately 1.5K Ohms. Figure 1 shows an example of this connection using I/O Channel 1:




FIGURE 1


The first time temperature data is requested, a value of 999.99° (0xFF x 2 if in Binary Mode) is returned. Subsequent reads will return valid temperature data if a temperature sensor is properly configured and connected to the specified I/O port. If no sensor is connected, a Temperature command will always return 999.99°.

Note 3 – Cat5 cable lengths of greater than 100 feet may require a pullup resistor value of less than 1.5K Ohms in order to achieve usable rise times at the sensor. The minimum safe resistance for the pullup resistor is 240 Ohms.

8.0 RETURN DATA TYPES

By default, the DLP-IO8 returns data to the host PC in the form of ASCII text such that it can be easily displayed and read using a simple terminal emulator. Alternatively, data can be returned in binary form requiring the user's host app to calculate the voltage and temperature values. The commands used to set the return data types (0x60 and 0x5C) are shown at the end of Table 1.

9.0 MECHANICAL DIMENSIONS IN INCHES (MM) (PRELIMINARY)



10.0 DISCLAIMER

© DLP Design, Inc., 2006 - 2013

Neither the whole nor any part of the information contained herein nor the product described in this manual may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder.

This product and its documentation are supplied on an as-is basis, and no warranty as to their suitability for any particular purpose is either made or implied. DLP Design, Inc. will not accept any claim for damages whatsoever arising as a result of the use or failure of this product. Your statutory rights are not affected. This product or any variant of it is not intended for use in any medical appliance, device, or system in which the failure of the product might reasonably be expected to result in personal injury.

This document provides preliminary information that may be subject to change without notice.

11.0 CONTACT INFORMATION

DLP Design, Inc.
1605 Roma Lane
Allen, TX 75013

Phone: 469-964-8027
Fax: 415-901-4859

Email Sales: sales@dlpdesign.com
Email Support: support@dlpdesign.com
Website URL: <http://www.dlpdesign.com>

Компания «Океан Электроники» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Поставка оригинальных импортных электронных компонентов напрямую с производств Америки, Европы и Азии, а так же с крупнейших складов мира;
- Широкая линейка поставок активных и пассивных импортных электронных компонентов (более 30 млн. наименований);
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Помощь Конструкторского Отдела и консультации квалифицированных инженеров;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Поставка электронных компонентов под контролем ВП;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- При необходимости вся продукция военного и аэрокосмического назначения проходит испытания и сертификацию в лаборатории (по согласованию с заказчиком);
- Поставка специализированных компонентов военного и аэрокосмического уровня качества (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Actel, Aeroflex, Peregrine, VPT, Syfer, Eurofarad, Texas Instruments, MS Kennedy, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Компания «Океан Электроники» является официальным дистрибьютором и эксклюзивным представителем в России одного из крупнейших производителей разъемов военного и аэрокосмического назначения «**JONHON**», а так же официальным дистрибьютором и эксклюзивным представителем в России производителя высокотехнологичных и надежных решений для передачи СВЧ сигналов «**FORSTAR**».



JONHON

«**JONHON**» (основан в 1970 г.)

Разъемы специального, военного и аэрокосмического назначения:

(Применяются в военной, авиационной, аэрокосмической, морской, железнодорожной, горно- и нефтедобывающей отраслях промышленности)

«**FORSTAR**» (основан в 1998 г.)

ВЧ соединители, коаксиальные кабели, кабельные сборки и микроволновые компоненты:

(Применяются в телекоммуникациях гражданского и специального назначения, в средствах связи, РЛС, а так же военной, авиационной и аэрокосмической отраслях промышленности).



Телефон: 8 (812) 309-75-97 (многоканальный)

Факс: 8 (812) 320-03-32

Электронная почта: ocean@oceanchips.ru

Web: <http://oceanchips.ru/>

Адрес: 198099, г. Санкт-Петербург, ул. Калинина, д. 2, корп. 4, лит. А